Monday, 1/7/2008 4:27:40 PM Date: User:

Kim Johnston **Process Sheet**

Customer

: CU-DAR001 Dart Helicopters Services

Drawing Name

: DOOR ASSEMBLY

Job Number

: 36652C

Estimate Number

: 12353

P.O. Number This Issue

: 1/7/2008

S.O. No. :

Part Number

: D41269403

Drawing Number

D412-694

: 2/28/2008

Prsht Rev. First Issue

: NC : 11

: SMALL /MED FAB Type

Project Number

: N/A

: 27340C

Drawing Revision

: C1

Material **Due Date**

Qty:

Each 1 Um:

Written By

Comment

Previous Run

Checked & Approved By

: Est Rev:

05.12.09

New Issue

KJ/RF

EC

Est Rev: В Est Rev:

06.04.18 06.07.11 New dwg rev. ecn781 Revised per B24660

ΚJ

Additional Product

Job Number:



Seq. #:

Machine Or Operation:

Description:

1.0 DC

DOCUMENT CONTROL





Issue red decal labels for D412-694-03.

2.0 14 COMPOSITE ASSY

Comment: COMPOSITE ASSEMBLY

COMPOSITE ASSEMBLY



· ·

D412-694-03 Drill Process

1- Drill pilot holes Ø(#30) using drill Jig D3144-T4 for the doublers. Drill (2) holes in two places Ø3/16" (0.188) for the slot opening. Router slot using D3144-T5/-T6 as per Dwg D412-694 page 3.Note: Ensure slot is aligned with mark for reference.



2- Drill Pilot holes Ø(#30) using drill Jig D3120-3T1 for bottom cover. Use unibit to open holes to Ø37/64" (0.578) for inserts as per Dwg D412-694 page 3.



3- Drill Pilot holes Ø(#30) using drill Jig DT8703-4 for hinges, top cover and D3131-1 spring. Use unibit to open holes to Ø37/64" (0.578) for inserts as per Dwg D412-694 page 3 & 4 (view MM-MM).



4- Drill Pilot holes Ø(#1/8") for clevis base and stop at top of the door using drill Jig DT8703-5. Open (1) hole Ø(#10) 0.193 for clevis base and (2) holes Ø(#19) 0.166 for stop as per Dwg D412-694 page 5 (section FF-FF.)



5- Drill Pilot hole Ø(#1/8") for clevis base at bottom of the door using drill Jig DT8703-6. Open hole Ø(#10] 0.193 for clevis base as per Dwg D412-694 page 5 (section FF-FF).

6- Ensure 17 1/16" from opposite edge of the door for Ø5/8" hole is in proper location top and bottom.

7- Drill through only (1) hole Ø(5/8") and pilot drill (2) holes Ø(#30) for insert. Open (2) holes to 37/64" (0.578) for clevis inserts as per Dwg D412-694 page 5 (section AA-AA).



Dart Aerospace Ltd

W/O:		,	WORK ORDER	CHANGES				
DATE	STEP	PRO	CEDURE CHANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
Part No):	PAR #:	Fault Category:	NCR: Yes	s No DQ	A:	_ Date: _	
				QA:	N/C Close	d:	_ Date: _	
NCR:		N	ORK ORDER NON-CON	IFORMANCE (NO	R)	,		

WORK ORDER NON-CONFORMANCE (NCR)							
	Description of NC		Corrective Action Section B			Approval	Approva
STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Section C	Chief Eng	QC Inspector
					1		
							-
	v						
						,	`
	STEP	STED Description of NC	STEP Description of NC Section A Initial	STEP Description of NC Section A Initial Action Description	STEP Description of NC Section A Initial Action Description Sign &	STEP Description of NC Section A Initial Action Description Sign & Verification Section C	STEP Description of NC Section A Initial Action Description Sign & Verification Section C Chief Eng

Monday, 1/7/2008 4:27:40 PM Date: User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: **Machine Or Operation:** 3.0 8000528 Insert Comment: Qty.; 21.0000 Each(s)/Unit Total: 21.0000 Each(s) Insert Batch A/R Hysol EA934NA ml08/02/27 Expiry Date: 4.0 COMPOSITE ASSY COMPOSITE ASSEMBLY Comment: COMPOSITE ASSEMBLY 1- Install inserts as per Dwg D412-694 page 3 & 5 (section AA-AA) and page 4 (view MM-MM). 2- Sand flush excess Hysol around the insert on both doors. 5.0 QC5 INSPECT WORK TO CURRENT STEP Comment: INSPECT WORK TO CURRENT STEP Inspect that inserts are flush with the surface. 6.0 COMPOSITE ASSY COMPOSITE ASSEMBLY Comment: COMPOSITE ASSEMBLY 1. Apply Primer filler and reducer around the inserts on both doors. Batch: (06 803 A/R 11045 Primer Filler 08-02-08 Batch: 106 803 **A/R** 12375S Reducer 7.0 QC5 INSPECT WORK TO CURRENT STEP Comment: INSPECT WORK TO CURRENT STEP 8.0 D31101 Comment: Qtv.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Escutcheon Batch D31103 9.0 Handle Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Handle B27539 Batch

Dart Ae	rospace Li	td							
W/O:			W	ORK ORDER CHANGES					
DATE	STEP	PR	OCEDURE CHA		Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
									1
								~~~	
Part No	:	PAR #:	Fault Cate	gory: No	CR: Yes	No <b>DQ</b>	A:	_ Date: _	<del></del>
					QA: N	C Close	d:	_ Date: _	
NCR:		•	WORK ORD	ER NON-CONFORMANC	E (NCR	)			
		Description of NC		Corrective Action Section B		Verific	ation	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Secti		Chief Eng	QC Inspector
	-		1			1	ŀ		

Date: Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: Machine Or Operation: 10.0 D3111041 Plate Assembly Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Plate Assembly M10536-17 Batch D31121 11.0 Comment: Qty.: Total: 2.0000 Each(s) Guide Batch 12.0 D31131 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Spring Batch 13.0 D31141 Pivot Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) **Pivot** 318630 Batch 14.0 D31165 Seal 110-031-4 Comment: Qty.: Total: 5.6700 f(s) 5.6700 f(s)/Unit Seal 110-031-4 Batch 15.0 D311611 Comment: Qty.: 1.5000 f(s)/Unit Total : 1.5000 f(s) **SEAL** B27241. Batch D3119041 16.0 Cover Assembly Comment: Qty.: 1.0000 Each(s) 1.0000 Each(s)/Unit Total: Cover Assembly Batch

Page 3

Form mrocess

Dart Ae	rospace l	Ltd						
W/O:			WC	ORK ORDER CHANG	ES		······································	
DATE	STEP	PROCEDURE CHANGE			Ву	Date Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
Part No	:	PAR #:	Fault Cate	gory:	_ NCR: Yes N	No <b>DQA</b> :	Date:	
						C Closed:		
NCR:			WORK ORD	ER NON-CONFORMA	ANCE (NCR)			
		Description of NC		Corrective Action Section		Verification	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Section C	Chief Eng	QC Inspector
	,							
		•						

Date: Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: **Machine Or Operation:** 17.0 D31201 Cover, Flat Pattern Comment: Qty.: 1.0000 Each(s) 1.0000 Each(s)/Unit Total: Cover, Flat Pattern M 10536-17 18.0 D31203 Comment: Qty.: Total: 1.0000 Each(s) 1.0000 Each(s)/Unit B18658A M10536-17 2008/2/15 Cover Batch D31251 19.0 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) D3125-1 Lever M10536-17 Batch 20.0 D31253 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Lever M10536-17 Batch 21.0 D31255 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Lever M10536-17 Batch 22.0 D31257 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Lever M10536-17 Batch 23.0 D31291 Lever Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Lever M10536-17 Batch

## **Dart Aerospace Ltd**

Dait Ac	103pace L	LU .					
W/O:		WORK ORDE	ER CHANGES	• • •	****		to the term of the
DATE	STEP	PROCEDURE CHANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approva QC Inspecto
	- - -						
,							
Part No	<u> </u>	PAR #: Fault Category:	NCR: Yes	No DQ	A:	Date:	
						Date: _	
NCR:		WORK ORDER NON-C	ONFORMANCE (NC	R)			
		Corrective A	otion Castian D	T			1

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
		Description of NC		Corrective Action Section B		Verification	Approval	Approval QC Inspector
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Section C	Approval Chief Eng	
								·

Date: Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: Machine Or Operation: Clevis Base 24.0 D31301 Comment: Qty.: Total: 2.0000 Each(s) 2.0000 Each(s)/Unit Clevis Base Batch 25.0 D31311 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Stop M10536-17 Batch 26.0 D31341 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Rod B27338 Batch 27.0 D31343 Rod Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) D3125-3 Rod B 21381 Batch Door Kit 28.0 D314007 Comment: Qty.: 1.0000 Each(s) 1.0000 Each(s)/Unit Total: Door Kit B36652C M106688 = 2008/15 Batch 29.0 D31431 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Clevis Batch 30.0 D31433 Clevis Comment: Qty.: 3.0000 Each(s)/Unit Total: 3.0000 Each(s) Clevis M10536-17 Batch

Page 5

Form: mrocess

# **Dart Aerospace Ltd**

W/O:			WORK ORDER	CHANGES				•
DATE	STEP	PR	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	
					-			
Part No	•	PAR #:	Fault Category:	NCR: Ye	s No <b>DQ</b>	Α:	Date:	

QA: N/C Closed: ____ Date: ____

NCR:	WORK ORDER NON-CONFORMANCE (NCR)							
		Description of NC		Corrective Action Section B		Verification	Annroval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Section C	Approval Chief Eng	QC Inspector
				·			<del>,</del>	
								į .

Monday, 1/7/2008 4:27:40 PM Date: User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: **Machine Or Operation:** 31.0 D31441 Doubler Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Doubler 318816 Batch 32.0 D3144105 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Doubler B23143 Batch 33.0 D3144107 Doubler 1.0000 Each(s) 1.0000 Each(s)/Unit Total: Comment: Qty.: Doubler B23144 Batch 34.0 D31451 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Bracket B26502. Batch Hinge Bracket 35.0 D31461 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Hinge Bracket B26709 Batch 36.0 D31471 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Pin 30824 Batch 37.0 D31491 2.0000 Each(s)/Unit Total: Comment: Qty.: 2.0000 Each(s) Striker Plate M10536-17. Batch


Dart Ae	rospace L	_td							
W/O:			V	WORK ORDER CHANG	ES			<u>.</u>	
DATE	STEP	PRO	OCEDURE CI	HANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
Part No	:	PAR #:	Fault Ca	itegory:	_ NCR: Yes	No DQ	A:	Date:	
	·				QA:	N/C Close	d:	Date:	
NCR:			WORK OR	DER NON-CONFORMA	ANCE (NC	R)			
DATE	OTED	Description of NC		· · · · · · · · · · · · · · · · · · ·	ion B	Verifi	cation	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign Date	& Sect	ion C	Chief Eng	QC Inspector

Monday, 1/7/2008 4:27:40 PM Date: User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: **Machine Or Operation:** 38.0 D31501 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Guide M 10536-17 Batch 39.0 D31541 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Key M10536-17 Batch 40.0 D31571 Spacer Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Spacer M10536-17 Batch 41.0 D3159041 **Bracket Assembly** Comment: Qty.: 3.0000 Each(s)/Unit Total: 3.0000 Each(s) **Bracket Assembly** Batch 42.0 D3159043 Bracket Assembly Comment: Qty.: 1.0000 Each(s) 1.0000 Each(s)/Unit **Bracket Assembly** Batch 43.0 AN52510R7 Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) Screw M106166 Batch 44.0 AN960JD6L Washer Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) Washer m5519 Batch

Dart Ae	rospace l	Ltd								
W/O:		14.80	W	ORK ORDER CH	ANGES					
DATE	STEP	PR	OCEDURE CHA	NGE		Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
·										
Part No	:	PAR #:	Fault Cate	gory:	NC	R: Yes I	No DQ	<b>A:</b>	Date:	
						QA: N/	C Close	d:	_ Date: _	
NCR:			WORK ORD	ER NON-CONFO	RMANCE	(NCR	)			
		Description of NC		<b>Corrective Action</b>	Section B		Verific	ation	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Descrip Chief Eng	tion	Sign & Date	Secti		Chief Eng	QC Inspector
								•		
					·					

Date: Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: Machine Or Operation: AN960JD8 45.0 Washer Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Washer M106112 Batch AN960JD8L 46.0 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Washer M6956 Batch 47.0 AN960JD10 Washer Comment: Qty.: 8.0000 Each(s)/Unit Total: 8.0000 Each(s) Washer 106167 Batch 48.0 AN960JD10L Washer Comment: Qty.: 13.0000 Each(s)/Unit Total: 13.0000 Each(s) Washer Batch 49.0 AN960JD10LL 29.0000 Each(s)/Unit Total: Comment: Qty.: 29.0000 Each(s) Washer M 19600 Batch 50.0 ALS463280 Comment: Qty.: 10.0000 Each(s)/Unit Total: 10.0000 Each(s) Insert M17841 Batch 51.0 BSP45 Commercial Rivet Comment: Qty.: 34.0000 Each(s)/Unit Total: 34.0000 Each(s) Commercial Rivet 20 x M 106937 Batch

Dart Ae	rospace	Ltd							
W/O:	T	*. *	V	ORK ORDER CHANGES					
DATE	STEP	PRO	PROCEDURE CHANGE			Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
Part No	:	PAR #:	Fault Cat	egory:NC	R: Yes	No <b>DQ</b>	A:	Date:	
					QA: N	I/C Close	d:	_ Date: _	
NCR:		W	ORK OR	DER NON-CONFORMANCE	(NCF	₹)			
		Description of NC		Corrective Action Section B	<del></del>	Verific	ation	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign 8 Date	Secti		Chief Eng	QC Inspector
								<u> </u>	



Dart Ae	rospace L	τα										
W/O:			WORK ORDER CHANGES									
DATE	STEP	PF	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approva QC Inspecto					
		,		·								
			194-194-194-194-194-194-194-194-194-194-									
Part No	·	PAR #:	Fault Category:	NCR: Y	es No DC	A:	_ Date: _					
				QA	: N/C Close	ed:	Date: _					
NCR:			WORK ORDER NON-CON	FORMANCE (N	CR)	-						
·												

NCR:			WORK ORD	DER NON-CONFORMANO	CE (NCR)			
		Description of NC		Corrective Action Section B		Verification	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Section C	Chief Eng	QC Inspector

Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Drawing Name: DOOR ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: Machine Or Operation: MS203922C15 59.0 Comment: Qty.: Total: 7.0000 Each(s) 7.0000 Each(s)/Unit Pin M101340 Batch 60.0 MS21042L3 Comment: Qty.: 7.0000 Each(s)/Unit Total: 7.0000 Each(s) Nut M105558 Batch 61.0 MS21042L06 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Nut M106612 Batch 62.0 MS24665151 Cotter Pin Comment: Qty.: 11.0000 Each(s)/Unit Total: 11.0000 Each(s) Cotter Pin m14526 Batch SCREW 63.0 MS24694C4 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) **SCREW** Batch 64.0 MS24694S53 SCREW Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) **SCREW** Batch SCREW 65.0 MS24694S56 Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) **SCREW** M104407 Batch

## **Dart Aerospace Ltd**

W/O:		WORK ORDER O	CHANGES				
DATE	STEP	PROCEDURE CHANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
Part No	:	PAR #: Fault Category:	NCR: Yes	No DQ	A:	_ Date: _	
			QA:	N/C Close	d:	_ Date: _	

NCR:		,	WORK OF	DER NON-CONFORMAN	CE (NCR)			
5475		Description of NC		Corrective Action Section B		Varification		A
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	- Verification Section C	Approval Chief Eng	Approval QC Inspector
				,				
		,					***************************************	
								_
· · · · · · · · · · · · · · · · · · ·								
							a.	
							:	

Date: Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Customer: CU-DAR001 Dart Helicopters Services Drawing Name: DOOR ASSEMBLY Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: Machine Or Operation: 66.0 MS24694S60 Screw Comment: Qty.: Total: 4.0000 Each(s) 4.0000 Each(s)/Unit Screw Batch MS25281R6 67.0 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Clamp m 19098 Batch 68.0 MS27039106 Comment: Qty.: 12.0000 Each(s)/Unit Total: 12.0000 Each(s) Screw M106815 Batch 69.0 MS27039108 Screw Comment: Qty.: 6.0000 Each(s)/Unit Total: 6.0000 Each(s) Screw M105076 Batch 70.0 MS35206231 Screw Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Screw Batch 71.0 MS35650305T Nut Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) Nut M11786 Batch 72.0 MS518597 Washer Comment: Qty.: 3.0000 Each(s)/Unit Total: 3.0000 Each(s) Washer M11822 Batch

	rospace						
W/O:		WORK ORDER C	HANGES				
DATE	STEP	PROCEDURE CHANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
~==							
Part No	:	PAR #: Fault Category:	NCR: Yes	No D	QA:	_ Date: _	
			QA:	N/C Clos	ed:	_ Date: _	
NCD.		WORK ORDER NON-CONF	ORMANCE (NC	R)			

NCR:	İ	V	VORK ORD	ER NON-CONFORMAN	ORK ORDER NON-CONFORMANCE (NCR)			
		Description of NC		Corrective Action Section B		Verification	Annroval	Annroval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Section C	Approval Chief Eng	Approval QC Inspecto
								•
				,				
· · · · · · · · · · · · · · · · · · ·							÷	
	·							

Monday, 1/7/2008 4:27:40 PM Date: User: Kim Johnston **Process Sheet** Customer: CU-DAR001 Dart Helicopters Services Drawing Name: DOOR ASSEMBLY Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Description: Machine Or Operation: 73.0 NAS116910L Washer Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) Washer m 11753 Batch 74.0 NAS38868F Comment: Qty.: Total: 15.0000 Each(s) Screw m 19098. Batch 75.0 NAS391B6P Washer Comment: Qty.: 16.0000 Each(s)/Unit Total: 16.0000 Each(s) Washer Batch 76.0 NAS43DD340 Spacer Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Spacer M11737 Batch 77.0 COMPOSITE ASSY COMPOSITE ASSEMBLY Comment: COMPOSITE ASSEMBLY D412-694-03 Assembly Process 1- Install top/bottom of the door, D3112-1 Guard, D3130-1 Clevis Base and D3131-1 Stop (top only) as per Dwg D412-694 page 5 (section AA-AA & FF-FF). 2- Install D3111-041 Plate Assembly. If needed, install temporary D3110-3 Handle as per Dwg D412-694 page 5 (view W and section BB-BB). Note: Adjust D3111-041 high with washer as required. Check that the D3154-1 key doesn't touch the base of the door.

- 3- Assemble Rod as per Dwg D412-694 page 5 (view W)
- 4- Assemble D3147-1 Pin to the lever as per Dwg D412-694 page 5 (section AA-AA & FF-FF).
- 5- Connect Rods and D3111-041 Plate Assembly as per Dwg D412-694 page 5 (view W).
- 6- Install D3111-041 and mechanism in place. Use D3110-3 Handle to make lock and mechanism of the rod work properly. Mark the center NAS1169-10L washer into the door and drill (#10) Ø0.193". C'sink Ø0.385 x 100° from far side of the door. Ensure D3111-041 is level with inside door surface as per Dwg

Dart Ae	rospace l	Ltd								
W/O:			W	ORK ORDER CH	IANGES					
DATE	STEP	PR	OCEDURE CHA	NGE		Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
·										
Part No	•	PAR #:	Fault Cate	gory:	NCI	R: Yes	No <b>DQ</b>	A:	Date:	
						QA: N	C Close	d:	_ Date:	
NCR:			NORK ORDI	ER NON-CONFO	PRMANCE	(NCR	)			
D.4.T.E.	oren	Description of NC		Corrective Action	Section B		Verific	ation	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	otion	Sign & Date	Secti		Chief Eng	QC Inspector
										:
							1			

Date: User:

Monday, 1/7/2008 4:27:40 PM

Kim Johnston

**Process Sheet** 

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: DOOR ASSEMBLY

Job Number: 36652C

Part Number: D41269403

Job Number:



Seq. #:

Machine Or Operation:

Description:

D412-694 page 5 (view W).

7- Install (1) D3159-041 bracket assembly to side of the window. Transfer hole from the door to D3159-041 bracket: Drill Ø(#30) C'sink for the rivet (note: use 1" pitch holes) as per Dwg D412-694 page 5 (view W) and (section LL-LL).

8- Drill (#19), C'sink Ø0.332 x 100°. Install MS25281-R6 Clamp as per Dwg D412-694 page 5 (view W). Ensure Rod moves freely when installing clamps.

9- Install (1) D3159-043 bracket assembly. Transfer (2) holes from the door to the bracket. Install (1) M7885/3-4-5 rivet and install the second rivet with the doubler.

Note: Layout properly as per Dwg D412-694 page 5 (view W). Note: Second hole will be done with doubler and seal.

10- Drill (4) (#10) Ø0.193" holes from D3150-1 guide by laying out doublers with temporary seal segment with strike plate. Check location of strike plate by laying out small and large door together. Note: Position strike plate when big door is in locked position.

- 11- Open (#30) pilot hole to Ø"G" (0.261) in the door for ALS4-632-80 insert. Install insert as per Dwg D412-694 page 3.
- 12- Install Doublers and D3159-041 bracket. Cut slot openings from the door to D3116-5-0680 Seal as per Dwg D412-694 page 3 (section JJ-JJ)
- 13- Install D3150-1 Guide top/bottom as per Dwg D412-694 page 5 (view DD & CC).
- 14- Install Hinge Bracket and D3113-1 Spring as per Dwg D412-694 page 3 & 4 (view MM-MM).

15- Install top/bottom Covers. Attach D3116-11-0180 Seal as per Dwg D412-694 page 3.

RTV732 Clear A/R

Batch: M 105700

Expiry Date: 33 July 2009

FOR D412-694-011 ONLY

16- Drill Pilot holes Ø(#1/8") for D3119-041 cover using drilling Jig D3119-041T1/T2 as per Dwg D412-694 page 3. Trim D3119-041 Cover Assembly and transfer Ø(#30) holes using hole finder tool from the door to the cover. Open holes to Ø5/32" (0.156).

78.0

QC5

INSPECT WORK TO CURRENT STEP

Comment: INSPECT WORK TO CURRENT STEP

Install door on mock up helicopter to insure proper fit and function.

# **Dart Aerospace Ltd**

W/O:		WORK ORDER C	HANGES				
DATE	STEP	PROCEDURE CHANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approvai QC Inspector

Part No:	PAR #:	Fault Category:	NCR: Yes No DQA:	Date: <u>08/09/2</u> 0
			QA: N/C Closed:	Date:

NCR:		W	ORK OR	DER NON-CONFORMANCE	E (NCR)			
		Description of NC		Corrective Action Section B			Approval	Approval
DATE	STEP	Section A	Chief Eng. Chief Eng. Date		Sign & Date	Verification Section C	Chief Eng	QC Inspector
08 07 21	78	Scrap one D3150-1 When install door on Mak up fortest		Destroy it and replace by new-one D3150-1 m 10536-17 guide	M   08   02   21			
, ,		Mak up fortest	Posiuja	D3150-1 M 10536-17 guide		form of	prior	bosori
					-			
							}	

Date: Monday, 1/7/2008 4:27:40 PM User: Kim Johnston **Process Sheet** Customer: CU-DAR001 Dart Helicopters Services Drawing Name: DOOR ASSEMBLY Job Number: 36652C Part Number: D41269403 Job Number: Seq. #: Machine Or Operation: Description: 79.0 SMALL FAB 1 SMALL & MEDIUM FAB RESOURCE 1 Comment: SMALL & MEDIUM FAB RESOURCE 1 (Put red label inside before puting the cover D3119-041/or Vip trim) ml08/02/21 1- Install D3119-041 Cover and Assemble Handle as per Dwg D412-694 page 3 & 5 (section BB-BB). Align properly. 80.0 INSPECT WORK TO CURRENT STEP QC5 Comment: INSPECT WORK TO CURRENT STEP 81.0 PACKAGING 1 PACKAGING RESOURCE #1 Comment: PACKAGING RESOURCE #1 Identify and Stock Location: 82.0 QC21 Comment: FINAL INSPECTION/W/O RELEASE mi 2008/2/26 Job Completion

Dart Ae	rospace l	Ltd							
W/O:			W	ORK ORDER CHANGE	S				
DATE	STEP	PR	OCEDURE CH	ANGE	Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
				-					
·									
Part No	:	PAR #:	Fault Cate	egory:				Date: Date:	
NCR:			WORK ORD	ER NON-CONFORMAN	ICE (NCR	)			
		Description of NC		Corrective Action Section		Verific	ation	Approval	Approval
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Secti		Chief Eng	QC Inspector
							!		
								:	
	L								

dy 6	Oby -82	Ogy 48	G G	Part Number	Description
X				D412-894-01	DOORASSEMBLY
	X			D412-694-02	DOORASSEMBLY
		X		D412894-03	DOORASSEMBLY
	1		X	D412-694-04	DOORASSEMBLY
				· · · · · · · · · · · · · · · · · · ·	
		1	1	D3110-1	ESCUTO-EON
	1	1	1	D3110-3	HANDLE
1	1			D3110-5	HANDLEASSEMBLY
	1	1	1	D3111-041	PLATE ASSEMBLY
		2	2	D3112-1	GUIDE
	1	1	1	D3113-1	SPRING
	_	1	1	DB114-1	PIVOT
1	1	_	_	D3115-1	BRACKET
		1	1	D3116-11-0180	SEAL
	<del>                                     </del>	1	1	D3116-5-0680	SEAL
1	1	_	_	D3116-7-0680	SEAL
1	1	_	_	D3116-9-0770	SEAL
Ė	T -	1		D3119041	COMERASSEMBLY
	1	ΙĖ	1	D3119-042	COMERASSEMBLY
	1	1	<del>' -</del>	D3120-1	COMER COMER
	$^{-}$	<del></del>	1	D3120-2	COMER .
<b>-</b>	1	1	<u> </u>	D31203	COMER .
ļ	$\overline{}$	<u> </u>	1	D31204	COMER .
3	3	$\vdash$	<u> </u>	D3121-041	BRACKET ASSEMBLY (ROLLER)
Ť	۲-	<del></del>		D3121-043	BRACKET ASSEMBLY (ROLLER)
Ė	1	_		D3121-044	BRACKET ASSEMBLY (ROLLER)
1	1	_	_	D3122-1	LEVER
2	2	_	-	D3123-1	CAM
1	۱ì			D3124-1	HOOK
+	1	_	-	D3124-2	HOOK
	<del> </del> -	1	1	D3125-1	LEVER
	1	1	i	D3125-3	LEVER
_	+	1	1	081255	LEVER
-	<del> </del>	1	÷	D8125-7	LEVER
1	1		-	D3126-1	
÷	1	_		031263	BRACKET ("SLIDER")
5	5	$\vdash$	-	D3126-5	BRACKET (SUDBT)
Ť	1			D3127-1	BRACKET (SUIDER)
	+ '	1	1	D3128-1	SPACER
-	1	2	2	D3129-1	LEVER
	-	2	2	D3130-1	CLEVIS BASE
-	+	-	1	D3131-1	
1					STOP
	1	-		D3132-041 D3132-042	RODWELDMENT
	1		-		RCOWELDMENT PROPERTY
1	+∸-			D3133-041	RODVEDMENT
	$\vdash$	1	1	D3133-042	RODVELDMENT
	+ -	+	<u> </u>	D3134-1	ROD
1			1	D3134-3	ROD
	···	_		D3135041	HANDLEWELDWENT
1	1			D3137-046	BRACKET ASSEMBLY
	-			D3138-1	COMER COMER
1	1			D3138-2	COMER
	11			D3139-1	GUARO
_1_	1		_	D31393	GUARO
1	1			D3139-4	GUARO
		$\dashv$		D3140-05	DOOR
اغلا	2	<del>-</del>		D3140-06	DOOR
<del>G</del>	玉	1	<u>-</u> ,-	D3140-07	DOOR
	띷		1	D3140-08	DOOR
(2)	. P	<del>-</del>		D3141-1	SPRING
70	$\mathcal{O}$	1	1	D3143-1	a.evis
Z	ايرا	3	3	D3143-3	CLEVIS
	1 4	1		D3144-1	DOUBLER
1-				D31443	DOUBLER
,	<b>  </b>	1		D3144-105	DOUBLER
	. !	1		D3144-107	DOUBLER
1				D3144-109	DOLELER

1	-02	-03	-04	Part Number	Description
	1			CB144-111	DOLBER
	1			D3144-115	COUBLER
			1	D3144-117	DOUBLER
			1	D3144-121	DOUBLER
			1	D3144-119	DOUBLER
	1			C3144-123	DOLBLER
1	1			D3144-13	COUBLER
		1		D3145-1	HNGEBRACKET
			1	D3145-2	HINGEBRACKET
-	_	1	<u> </u>	D3146-1	HNGEBRACKET
			1	D3146-2	HINGEBRACKET
		2	2	D3147-1	FRN
2	2		<u> </u>	D3148-1	Q.EVIS
_		2	2	D3149-1	STRIKERPLATE
		2	2	D3150-1	GUDE
1	1		-	D3151-041	DOUBLERASSEMBLY
1				D3152-041	BRACKET ASSEMBLY
÷	1		$\vdash$	D3152-042	BRACKET ASSEMBLY
$\dashv$	<u> </u>	1	1	D3154-1	KEY ASSEMBLY
1	1	·	<del></del>	D3155-041	BRACKET ASSEMBLY
1	1		├	D3155-042	BRACKET ASSEMBLY
2	2		_	D3156-1	BRACKET
	-	2	2	D3157-1	SPACER
$\rightarrow$		3	3	D3159-041	BRACKET ASSEMBLY
-1	-	1	-		
			<del>                                     </del>	D3159-043	BRACKETASSEMBLY
10	10		<del>  '-</del>	D3159-044	BRACKETASSEMBLY
1	- U	1	<del></del>	D3162-041	BRACKETASSEMBLY
+	$\vdash$	<del>-</del> -	<u> </u>	D3162-043	BRACKETASSEMBLY
	-	<u> </u>		D3162-044	BRACKETASSEMBLY
긔	1		├	D3163-041 D3163-042	COMERASSEMBLY
7					COMER ASSEMBLY
			<b></b>	D3183-041	BRACKETASSBABLY (ROLLER)
1	1		┝	D3183-042	BRACKET ASSEMBLY (ROLLER)
2	2		ļ	D3203-1	HANDLEASSBABLY
5	55	~		D3308-1	DUBLER
<del>30</del>	10	21	21	80-005-2-8	INSERT (OR SL2052-3-4)
		4	4	AN525-10R6	SCREW
8	8			AN52510F7	SOREW
		8	8	ANDSOLID10	WASHER
18	18	20	30	ANDBOUDIOL	WASHER
13	13	32	3	ANDEOLIDIOLL	WASHER
6	6		-	ANDGOLD416L	WASHER
_		4	4	AN960.ID6L	WASHER
6	-6		<u> </u>	AN980.ID8	WASHER
		2	2	ANDSOLIDBL	WASHER
		_2	2	ANDROLDBUL	WASHER
_		10	10	ASL4632-80	INSERT
87	87	50	50	BSP45	RIVET
		12	12	PW10-032	WASHER
		6	6	FW4-032	WASHER
12	12		Ļ	M7885/2-4	RIVET (OROR3213-4-3)
_		3	3	M7886/3-4	RIVET (OR OR321243)
		2	2	MS20392-1C11	PIN
		7	7	M520392-2C15	PIN
2	_2		ليا	MS20392-2C17	PIN
2	. 2	2	2	M520392-209	PIN
2	2			MS20392-3C21	PIN
8	8			MS20426AC3	RIVET
12	12			M7885/3-4	RIVET

Oby St	8.5	Cty GS	CEY OF	Part Number	Description
-20	20			MESDESADI	FIVET
		6	6	MS21042L06	NUT
6	6	2	2	M521042L08	NUT
		5	5	MS21042L3	NUT
4	4			M5210421.4	NUT
4	4			MS21072-L3	NUTPLATE
6	6	9	9	M524665-151	COTTERPIN
4	4			MS24693-S271	SOREW
		2	2	MS24694-C4	SCREW
4	4			M524694-C5	SCREW
6	6			M624694-95	SCREW
18	18			M524694-S50	SCREW
		4	4	M524694-S56	SOREW
		2	2	M524694-953	SOREW
		4	4	MS24891-990	SOREW
4	4			M524694-598	SOREW
		2	2	M525261-R6	CLAMP
2	2	2	2	MS27039-1-05	SCREW
14	14	_12	12	M527039-1-06	SOREW
13	13	6	6	MS27039-1-08	SOREW
		2	2	MS35206-231	SCREW
2	2			MS35275-233	SOREW
2	2			M535649-264	NUT
L		4	4	MS39960-305T	NUT
2	2			MS35660-3252	NUT
2	2	3	3	MS51869-7	WASHER .
L		4	4	NAS1169-10L	WASHER_
L		14	14	NAS3886-8P	SOREW
		15	15	NAS391B6P	WASHER
7	7			NAS43000-10	SPACER
6	6			NAS43CD3-14	SPACER
		2	2	NAS43003-40	SPACER

### GENERAL NOTES:

POR ADJUSTMENT OF LOCKING MEDIANISM FRICK TO DOOR ASSEMBLY, SET AT UNLATCH POSITION AND ADJUST SOFEWINA APOUNTIL 03 124-1/2 HOOK RESTS AGAINST OUTOUT SHOWN IN WIEWN.

/ 2 \ IF REQUIRED, NOTCH D0125-1 LEMER (REP.) TO CLEAR THE D0130-1 CLEMS BASE.

REF. 2 PLACES) TO ALLOW FOR PULL TRAVEL OF THE LEMER.

HOLES AND PARTS TO BE LOCATED PER DRILLING JIGS, 830-2300001; D3144-TV-T2-T3; D18703-3; D3162-041T1 (FCR-O1 DOCR ASSY); B30-2300042; D3144-TV-T8-T9; D18703-9; D3162-041T2 (FCR-02 DOCR ASSY); D3144-T4-T9-T8; D3119-041T1; D312-TV-12 (FOR-03 DOORASSY); D3144-T10-T11/-T12 D3119-042T1; D3112-T14-T2 (FOR-04 DOORASSY)

A INSTALL INSERTIS PER DART OS COS. LOCATE TO MATCHHOLE PATTERN OF MATINGPARTS

- 5) TOLEPANCES ARE PER DIRT OSI 018 UNLESS OTHERANSE NOTED
  6) ALL DIMPNSIONS ARE ININDHES
  7) IDENTIFY DA12-884-014-024-024-01-DOCRASSEMBLIES USING D2729-1 DECALS

Cı	₩ 06.03.28	ADD OPTION M7885/3-4		
С	05.11.23	ADD D3137-045, D3162-043/-044; REMOVE D3137-041; UPDATED NOTES		
В	04.10.07	UPDATE DRAWING		
Α	02.05.21	NEW ISSUE		
DESIG	CP RF	DART AEROSPACE LTD. HAMKESBURY, ONTARIO, CANADA		

### COPYRIGHT @ 2002 BY DART AEROSPACE LTD.

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS COMDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Α		02.05.21	NEW ISSUE	
DESIGN CP		RF	DART	DART AEROSPACE LTD. HAWKESBURY, ONTARIO, CANADA
CHECK	ED ,	APPROVED	DRAWING NO.	REV. C
	#	1	D412-694	· SHEET 1 OF 6
DATE			TITLE	SCALE
05.1	1.23		DOOR ASSEMBLY	NTS .

UNCONTROLLED COPY
SUBJECT TO AMENDMENT
SUBJECT TO AMENDMENT
WITHOUT NOTICE ENGINEERI

